Care Work Frocedures - Chinici Cervicing	
General/Brief Description of task	Scheduled preventative maintenance of chillers
Frequency of task performed	Yearly
Hazards Identified	None
P.P.E. required: Special tools required (if any)	Rubber Boots
Safe Work Procedure	Visually inspect worksite for possible hazards

Safe Work Procedures - Chiller Servicing

P.P.E. required: Special tools required (if any)

• Rubber Boots

• Visually inspect worksite for possible hazards
• Ensure proper lockout / tagout of chiller
• Refer to "Lockout / Tagout Procedures" as found in this section
• Refer to PM # as found in Appendix 'B'