

# Smart Board



- The smart board can be used to navigate presentations, annotate documents, and for 'SMART Pen' control.
- The system automatically activates when you log in to the classroom computer.
- Remove any of the pens from its storage slot along the bottom edge of the board. When using the pens, apply **gentle pressure** to the surface of the board to avoid damage.



*If you notice that the pens are inaccurate or not functioning properly, the device may need to be re-oriented. Please call classroom support to request this procedure.*